

---

## Display Page Operations

All page operations use the Display menu.

**To unlock the display for editing:** Double click anywhere in the Window and press Yes to unlock. Alternatively, select the Display, Lock menu item and switch off (repeat to switch on again).

**When the display lock is off:**

view port settings can be modified (double click the view-port)  
system colors can be changed (Options, System, Colors menu item enabled)  
the packet format can be changed (Transfer, Pkt format menu item enabled)

**To save a page at any time:** select the Display, Save menu item

**To make a copy of a page:** select the Display, Save as menu item and enter the new page number. TPS will change to the newly created page.

**To merge a page with the current page:** select the Display, Merge menu item and enter the page number to be merged.

**To append the current page to another page:** select the Display, Append to menu item and enter the page to append to. TPS will change to the newly created page.

**To rename (re-number) the current page:** select the Display, Rename menu item and enter the new page number. TPS will change to the newly created page and delete the old page.

**To delete the current page:** select the Display, Delete menu item. TPS will delete the current page but not change to any other page so the display will appear blank except the bottom three lines of the window, i.e. the system display. You will not be able to turn back to the deleted page after turning to another page.

### Miscellaneous

If you delete all the view-ports on a page the page will be removed.

Empty pages cannot be created and are technically illegal, albeit harmless.

A page can contain up to 1024 view-ports.