
View-port Operations

You must unlock the display before you can perform any of these operations. To do this, double click anywhere in the TPS Window and press **Yes** to unlock. Alternatively, select the **D**isplay, **L**ock menu item and switch off (repeat to switch on again).

To create a view-port: Always modify a copy of an existing view-port - see below to make copies. Alternatively, double-click the left mouse button over an empty area of the display and press the **N**ew button, it will popup a list of parameters from the current page and the templates page 9998. Selecting a parameter will make a copy on the current page.

To copy a view-port (on the same page): put the cursor in the view-port area, hold down the shift key and then press and hold down the left mouse button dragging a copy of the port to a new position.

To copy a view-port (from a different page): double-click the left mouse button over an empty area of the display and press the **C**opy **f**rom button to popup the 'Open Page' dialog box. Enter the page number from where you wish to copy the view-port and then select a parameter to be copied from the popup list.

To copy a view-port (to a different page): put the cursor in the view-port area and double click. Press the **C**opy **t**o button to popup the 'Open Page' dialog box and enter the page number to where you wish to copy the view-port.

To move a view-port: put the cursor in the view-port area, press and hold down the left mouse button and drag the port to its new desired position.

To change a view-port's settings: put the cursor in the view-port area and double click. Press the **S**ettings button to popup the view-port settings dialog box.

To delete a view-port: Put the cursor in the view-port area and double click. Press the **D**elete button to delete the view port. You will then be prompted for confirmation.